
Hydroponic Canna Smart 3




Welcome to the world of indoor gardening!

The **Hydroponic CANNA SMART GARDEN 3** is an innovative indoor garden that cares for itself and grows healthy plants for you.


Experience all the benefits of having your own indoor garden, no matter where you live.



Hydroponic Canna Smart Garden 3




How to assemble it?




Lets start growing!

Mix 1 Sachet Hydroponic water soluble fertilizer with 2 litres of water.



Start the Growing cycle.

Each time you Push the Power Button the Grow light timer will change the cycle:



Push the Power

RED: Grow Light will be on all the time

BLUE: Grow Light will be **16** Hours **ON** and **8** hours **OFF**

GREEN: Grow Light will be 12 Hours ON and 12 hours OFF

Tips to successfully grow your Cannabis Plants.

- Use LED grow light Timer mode 2 BLUE: 16 hours ON and 8 hours OFF.
- If the water level gets too low, as indicated by the red water level floater, please top up with fertilizer solution until you reach max volume.
- Ensure the room temperature does not stay below 16 C.
- When the plant reaches the height of the LED light, it's time to plant the Canna Pod in the garden or in a container with living organic soil.
- After the Canna Pod has been removed, clean the Canna Pod container and the water tank thoroughly. Refill the Canna Pod containers with pre-seeded Canna Pods from Cannamart - you can purchase these separately.





Consumables:




View here.

How to place a new Canna Pod in the plant pod holder.









- 1. Insert the Canna Pod into the holder.
- 2. Place the Canna Pod holder back into the basin filled with Hydroponic water soluble fertiliser. Make sure it is filled to the max level to ensure the new Canna Pod can absorb the water.

Safety Instruction:

- Only connect the CANNA SMART GARDEN 3 in indoor areas to a properly installed socket with a protective conductor.
- USER MAINTENANCE Any servicing is to be performed by an authorized electrician. Disconnect power before servicing or replacing accessories.
- DO NOT SUBMERGE Do not immerse cord in water or other liquid.
- RISK OF ELECTRIC SHOCK Never touch the mains plug with damp hands. Never pull the mains plug
 out of the socket by the mains cord. Always switch the unit off and pull the mains plug out of the
 socket when you are not using the unit, cleaning it or in the event of a fault.
- FOR HOUSEHOLD USE ONLY
- Only use the CANNA SMART GARDEN 3 as described in this user manual. Any other use is deemed improper and may result in damage to property or even personal injury. The CANNA SMART GARDEN 3 is not a children's toy and children using it must be supervised by an adult at all times.
- Cannamart.co.za accepts no liability for damage caused by improper or incorrect use.

